





Tintmaster 300


Sparepartsbook




Spareparts List				
ITEM	SP NUMBER	DESCRIPTION	REMARKS	QTY
10	1811170-SP	Door,top,L/R,TM300		2
12	1811168-SP	Panel,back,TM300		1
13	1863041-SP	Punch manual 24mm	Page 4653	1
15	1863994-SP	Punch manual 46mm,TM300/HA150		1
20	1811612-SP	Panel,side,L/R,fl.,TM300/HA150		2
21	1862332-SP	Latch,slide,40-525,set 2pcs.		6
23	1863995-SP	Punch manual 46mm+panels,TM300		1
24	1813310-SP	Front & indicator glass TM		1



Spareparts List				
ITEM	SP NUMBER	DESCRIPTION	REMARKS	QTY
05	1811170-SP	Door,top,L/R,TM300		2
06	1862860-SP	Quad,panel,latche,SET		2




Spareparts List				
ITEM	SP NUMBER	DESCRIPTION	REMARKS	QTY
11	1862332-SP	Latch,slide,40-525,set 2pcs.		2
14	1860413-SP	Heating assy,Ha-s/m/l		1
15	1110340-SP	Wheel,swiveling,set 4 pcs		2




Spareparts List				
ITEM	SP NUMBER	DESCRIPTION	REMARKS	QTY
01	1862332-SP	Latch,slide,40-525		2
09	1812793-SP	Shelf without handle		1

03




14


Spareparts List				
ITEM	SP NUMBER	DESCRIPTION	REMARKS	QTY
03	1862332-SP	Latch,slide,40-525,set 2pcs.		2
14	1812793-SP	Shelf without handle		1




Spareparts List				
ITEM	SP NUMBER	DESCRIPTION	REMARKS	QTY
03	1862474-SP	PCB HA2/4/600,TM300,with CD	up to 13/12/04	1
03	1863370-SP	Powerboard,HA,2002,5-phase		1
08	1861979-SP	Sensor2/4/8,step,H/Valve.H/Mi		1




Spareparts List				
ITEM	SP NUMBER	DESCRIPTION	REMARKS	QTY
11	1861979-SP	sensor5,tablehomesensor-assy		1
15	1120076-SP	Motor,step,w.coupler,TM300		1
16	1862844-SP	Gripper,spindle,kit,TM300		1




Spareparts List				
ITEM	SP NUMBER	DESCRIPTION	REMARKS	QTY
01	1862235-SP	Emergency,switch		1
05	1862403-SP	Switch,on/off,SO/SK		2
07	1861980-SP	Sensor5/6,TT,home/pos.Disp2002		1
12	1130071-SP	Motor,404156		1
13	1861978-SP	Sensor4,valveclosedsensor-assy		1
16	1811187-SP	Arm,valve,sensor,assy,TM300		1




Spareparts List				
ITEM	SP NUMBER	DESCRIPTION	REMARKS	QTY
01	A-08830BK-SP	Pump-canister,assy,3.5L,TM300		1
02	A-08810BK-SP	Pump-canister,assy,TM300		1
03	1804315-SP	TubeØ16*67,HAs/m/l,TM		5
04	1803345-SP	Tube,Ø16x148.5,HA/TM		5
05	1810154-SP	Aligmentring, BT24		1
06	1811159-SP	Turntable,24C,TM-300		1
11	A-08831BK-SP	Canister assy 3.5L TM300		1
12	A-08811BK-SP	Canister,assy,TM300		1
13	A-08812K-SP	Pump/bracket,assy,TM300		1
14	1811381-SP	Bush,drive,motor,agit,TM300		1
15	1811160-SP	Turntable,underplate,24C,Tm300		1
17	1803512-SP	Crank,assy,BA-b/f		1
19	1811176-SP	Bearing,turntable,TM300/HA150		1
20	1862832-SP	Brush,assy,TM300	Page 4639	1
22	1602782-SP	Fuse,10A,set,10pcs		1
23	1172160-SP	Fuse,2 Amp,set,10pcs		1
25	1861975-SP	sensor1,cansensor-assy		1
26	1862749-SP	Powersupply,assy,TM300/HA150		1
27	1862422-SP	Wheel,traversing,centric,35mm		3
31	1130071-SP	Motor,404603		1
34	1860062-SP	Motor,gearred DC,403.855,BT/HA		1




Spareparts List				
ITEM	SP NUMBER	DESCRIPTION	REMARKS	QTY
02	1752020-SP	Brush,BT/TM300		1
04	1801866-SP	Brushcontainer,BA-b/f		1
09	1860537-SP	Container,brush,assy,TM/BT		1




Spareparts List				
ITEM	SP NUMBER	DESCRIPTION	REMARKS	QTY
09	1863271-SP	Cantable assy, TM/ HAs/ ETm		1




Spareparts List				
ITEM	SP NUMBER	DESCRIPTION	REMARKS	QTY
01	1801626-SP	Plate,sup,bearing,set+pins		2
02	1152040-SP	Pin,dowel,nra f3x19,8 set25pcs		24
03	1803507-SP	Guide,cantable,HA/BA		1
04	4120908-SP	Nut,hex,7/16-28,index,pin,25pcs		1
08	1153701-SP	Cable,brake,set,L=600mm,2xbolt		1
12	1150071-SP	absorber,shock,oil,375mmstroke		1
13	1801628-SP	Frame,assy,cantable,HA/BA		1
19	1250250-SP	Spring,Pedal,Cantable,2pcs		1
21	1850261-SP	NutM8,nyloc,hex,din985,set10pc		1



Spareparts List				
ITEM	SP NUMBER	DESCRIPTION	REMARKS	QTY
01	1803539-SP	Lid,canister,Ba-b/f		1
02	A-R0115-SP	Pin split 1/16,set 100pcs		1
03	A-07165-SP	Blade,stir.,22PC/22PD,set,5pcs		1
04	A-R0329-SP	M/T 4x8mm,panhead,XR,NP.set50x		3
05	A-00311-SP	Stirrer,guide,bush, 25pcs		1
07	A-B011-SP	O-ring,BS011, 25pcs		1
08	A-03543-SP	Insert,canister, valve,10pcs		1
12	A-R0614-SP	MT1/4"BSWX1"Panhead set 50pcs		2
14	A-B015-SP	O-ring,BS015,set,25pcs		1
15	A-08488-SP	Spring, valve return,set,10pcs		1
17	1811180-SP	Shaft,agitation,canister,TM300		1



Spareparts List				
ITEM	SP NUMBER	DESCRIPTION	REMARKS	QTY
01	1807801-SP	Bush,tube,canister 22P		1
02	1362230-SP	O-Ring,can,vit,15.88x2,62 10st		2
03	1804315-SP	Tube,ø16x67,HAs/m/I,TM		1
04	1803345-SP	Tube,Ø16x148.5,HA/TM		1
09	A-B015-SP	O-ring,BS015,set,25pcs		1
15	A-R0614-SP	M/T,1/4"BSWx1",Panhead set 50pcs		3
16	A-03543-SP	Insert,canister,valve,10pcs		1
17	A-R0329-SP	M/T,4x8mm,panhead,XR,NP.set50x		1
18	A-08488-SP	Spring,valve return,set,10pcs		1



Spareparts List				
ITEM	SP NUMBER	DESCRIPTION	REMARKS	QTY
02	1801527-SP	Disc,pump,BT,25pcs		1
04	A-1801525-SP	Cap,tube,22P,BA16,set,5pcs		1
08	A-07133-SP	Cyl.reducer,Assy.7/8		1
10	A-BS122-SP	O-Ring,BS122,(valve/set 10pcs)		1
13	A-04075-SP	Solid,piston,teflon,set 10 pcs		1
14	A-R0036-SP	Bolt,1/4 BSWx5/8 SET 100 pcs		1
16	A-03532B-SP	Piston,sniff,back,black,10pcs		1
17	A-R0138-SP	S/Tap-6x5/8".pan.h.slt 25pcs		1
21	A-B011-SP	O-ring,BS011, 25pcs		1
22	A-03541B-SP	Nozzle,arm,seal,bl.,set, 10pcs		1
23	A-03534B-SP	Nozzle,out,f3/16"53P,set,10pcs		1
24	1801882-SP	Set,Sensor/resetplate BA 15/1		1
25	A-03541B-SP	Nozzle,arm,seal,bl.,set, 10pcs		1
26	A-03534B-SP	Nozzle,out,f3/16"53P,set,10pcs		1
27	1801882-SP	Set,Sensor/resetplate BA 15/1		1